



6mL

Multipurpose

Make up + care



Formula challenge

Mr. Timid

SOPHIM is proud to offer a formula answering:

Consumers' needs

Market trends

Formulators

Multipurpose product

Care

Make-up + Double heating and strong ingredients

Waterless

According rise in eco-conscious 2021 show streamlining their routines is to provide care. to reduce their carbon will also appeal during the benefits crisis".(1)

Mr.Timid offers various products contouring, blush lipstick.

Mintel, Mintel also analyses that As in many cosmetic sticks multipurpose products are makeup and haircare manufacturing, back on trend: "with the products launched since production of Mr.Timid thinking, consumers are ingredients which purpose

convenience connotations buyers of makeup think remain efficient and of multifunctional products skincare /skin protecting sensorial while are current cost-of-living important when buying makeup. In China, 61% of female users of face makup are make-up uses, such as interested in base products or with hydrating claims.(2)

more requires double heating.

footprint. The value and In the UK, 50% of female ingredients which could most submitted to heat.



- (1) Source: Mintel GNPD "2024 A year of innovation in colour cosmetics" published 22nd Mar 2023
- (2) Source: Mintel GNPD Kantar profiles/Mintel 2021

1 Mr. Timid

Phytosqualan, star ingredient

10% of Phytosqualan offers proven benefits (emolliency: moisturizing, TEWL reduction...) and is an asset for a make-up product offering care while enhancing the consumer's beauty. The multifunctional star-ingredient is also a sensory agent, thanks to its non-greasy touch and its ability to facilitate spreading.

Castor Oil for pigment dispersion

Castor oil helps to coat the pigments well. It is a great asset for pigment dispersion.



Butters, oils & waxes


- <u>Jojoba butter</u>: offers good heat resistance and less oxidation vs other butters. Melting feel.
- <u>Phytowax®18L57</u>: a subtle balance between emolliency and texture, ideal for a sensory stick.
- <u>Carnauba wax</u>: a complementary texture agent.
- <u>Plum oil</u>: a delicate gourmet oil to provide more sensory and a subtle fragrance.

PHASE	INCI	NAME	SUPPLIER	%
A	Helianthus Annuus Seed Oil	Sunflower Oil OR VIR	SOPHIM	28.5 (qsp)
А	Squalane	Phytosqualan	SOPHIM	10
А	Ricinus Communis Seed Oil	Castor Oil OR	SOPHIM	10
А	Simmondsia Chinensis Seed Oil (and) Hydrogenated Vegetable Oil	Jojoba Butter	SOPHIM	10
A	Copernicia Cerifa Cera	Carnauba wax	SOPHIM	9
А	Hydrogenated Olive Oil Stearyl Esters	Phytowax 18L57 OR	SOPHIM	8
А	Euphorbia Cerifera Cera	Candellila wax		8
A	Prunus Domestica Seed Oil	Plum oil OR VIR	SOPHIM	5
А	Prunus Armeniaca Kernel Oil	Apricot Kernel oil OR VIR	SOPHIM	5
А	Tocopherol (and) Helianthus Annuus Seed Oil	SkinFeel TOCO 70 NON-GMO	ООРНІМ	0.25
В	Ricinus communis seed oil (and) CI45410	Pigment		5
В	Ricinus Commhnis Seed Oil (and) CI 77491 (and) CI 77492 (and) CI 77499 (and) Polyhydroxystearic Acid	Pigment		1
С	Fragrance	FEMA Thé d'Azur, from PARFEX		0.25

PROCEDURE

Preparation:

- Weigh all the solid, pasty and liquid fats from the A batch into a suitable beaker.
- Heat the beaker in a water bath to 90°C, which
 is equivalent to 80-85°C in the beaker. Once
 the entire phase has become liquid, start
 stirring at a suitable speed to avoid
 incorporating air into the medium.
- Make sure all fats are melted and well dispersed. Add the two pigment dispersions from phase B under stirring at 80°C, taking care not to agrate the bulk.
- Check under the microscope that the pigments are well dispersed.
- Remove from water bath.
- Add perfume at around 70°C.
- Homogenize the bulk well before stopping stirring.
- Allow the bulk to cool to the core of the beaker to obtain a homogeneous crystal lattice.
- Depending on the quantity, cooling may take up to 24 hours.
- The bulk may be placed in cold storage at 10°C for one week before casting the sticks.
- Reheat just enough to 80°C to pour into sticks.
- Do not "overheat" the bulk (temperature and duration) to avoid damaging the perfume concentrate and oxidizing the bulk.





HOW TO USE?



As a lipstick

Use a brush to collect the product and apply to the lips.






As a creamy blush

Use a a chiselled sponge and gently tap on the cheekbone.





As contouring

Use the stick and lighlty draw your contour



Contact your sales representative:

florent.pinot@sophim.com juliette.prou@sophim.com boris.segalowitch@sophim.com

Order a sample: patricia.soler@sophim.com